

VOICECOM

VAA Battery Charger Operation Guide

Function

The function of the VAA Battery Charger is to enable SAFE and RELIABLE operation to charge VAA batteries and this guide has been designed to help you understand how to use your charger safely.

LED Status:

- Left LED is ACTIVE
- Right LED
 - RED = Charging
 - GREEN = Charging complete

Operation

Connect the charger to 240 V mains power and the turn master switch on the side of enclosure ON.

Check toggle switches are in the OFF position.

Ensure the batteries are securely seated in the charger before you switch ON to the battery “Charge – Latching” position.

Using LED status above observe the battery is being charged.

When fully Charged, put the battery to Sleep, by selecting “Sleep - Momentary” position before removing from the battery charger.

